

IFH Oil Storage Racks

Affixing Tank Labels

HOW TO AFFIX THE IFH COLORED LABEL



- 1** Tools Required:
 - Squeegee
 - Spray bottle (filled with water)
 - Clean rag
- 2** Wet down the IFH tank front with water. Ensure that the entire surface of the tank is wet.
- 3** Peel one side of the label from the protective backing and lay flat upside down on the backing.
- 4** Thoroughly wet the adhesive side of the label (include a few drops of liquid detergent in the water to improve the wetting properties).
- 5** Apply the wetted label to the wet tank face and align the label so that there is 1/2" of tank showing around the top, bottom and side of the tank.
- 6** Repeat steps 3 and 4 with the other half of the label and apply the label to the other side of the tank. Align the two label halves by sliding them into position. The labels should slide on the tank surface with a slight effort.
- 7** Using the squeegee start on one side of the tank and squeegee out the water from the sticker. Use motions from the center to the outside of the label.
- 8** Once all the water is squeezed out from behind the label, use your clean rag to dry the tank and label.

Your IFH tank label is now ready for admiring. You can use a standard marker to write the lubricant product name into the area provided.



PROACTIVE LUBRICATION MANAGEMENT

Lubrigard Ltd. C8-1175 Appleby Line, Burlington, ON, L7L 5H9 Tel 905-569-8600 Toll-free 800-268-2131 Fax 905-569-8605 URL <http://www.lubrigard.com>

LG-IFH-RACKS-TANK-LABEL-FAQ-2010-03-11