

Download the App



<https://bit.ly/oilapp>



<https://bit.ly/oaplay>

Download the Oil Analysis app from the App Store or Google Play. After installation, use your WebCheck credentials to login to the app.

Take your oil samples



1

Remove the sample label from the sample form and stick to the sample bottle.



2

Take the oil sample as you normally would and re-cap the sample bottle.



3

Ensure that the cap is securely tightened and wipe any excess oil from the sample bottle.

Complete sample submission with the asset tag booklet & the app



4

Using the app, scan the QR code of the machine the sample was taken from. Remove the tracking label from the sample form and stick to the asset log booklet.



5

Next, scan the sample label, and complete the sample information and submit the sample.



1

Login to the app using your WebCheck credentials. The app will cache your machines.



2

Once logged in, click on the "Scan QR Code" button.



3

Locate the machine that was sampled in the asset tag booklet and scan that QR code.



4

The asset is selected & sample submission screen is loaded. Click the "Scan" button.



5

Scan the sample bottle label from your oil sample for the selected machine.



6

The sample is now linked to the machine. Use the "SIMPLE" data entry mode to add info.



7

Select the sample date, take any pictures you want, add a comment if desired, then click the "submit sample" button




8

The sample info has been submitted to the laboratory where the QR code will be scanned, and the sample information automatically retrieved.



9

Submitted samples are listed. To update a samples info slide left. To delete a sample slide right.




EID:1749497

Area
TWINNING / WATSON #50
Machine ID
WATSON #50 BEARINGS BACK END (S/N K-853-1)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label



EID:1749496

Area
TWINNING / WATSON #50
Machine ID
WATSON #50 BEARINGS FRONT END (S/N K-853-1)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1723532

Area
TWINNING / WATSON #51
Machine ID
WATSON #51 BEARINGS BACK END (S/N K-777-3)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1839092

Area
TWINNING / WATSON #51
Machine ID
WATSON #51 BEARINGS FRONT END (S/N K-777-3)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1839082

Area
TWINNING / WATSON #52
Machine ID
WATSON #52 BEARINGS-BACK END (S/N K-853-3)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1839085

Area
TWINNING / WATSON #52
Machine ID
WATSON #52 BEARINGS-FRONT END (S/N K-853-3)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1726599

Area
TWINNING / WATSON #53
Machine ID
WATSON #53 BEARINGS-BACK END (S/N K-777-4)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1726600

Area
TWINNING / WATSON #53
Machine ID
WATSON #53 BEARINGS-FRONT END (S/N K-777-4)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1749503

Area
TWINNING / WATSON #54
Machine ID
WATSON #54 BEARINGS BACK END (S/N K-922-4)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label



EID:1749499

Area
TWINNING / WATSON #54
Machine ID
WATSON #54 BEARINGS FRONT END (S/N K-922-4)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1839098

Area
TWINNING / WATSON #55
Machine ID
WATSON #55 BEARINGS BACK END (S/N K-922-1)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1429032

Area
TWINNING / WATSON #55
Machine ID
WATSON #55 BEARINGS FRONT END (S/N K-922-1)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1681120

Area
TWINNING / WATSON #56
Machine ID
WATSON #56 BEARINGS BACK END (S/N K-853-2)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1839101

Area
TWINNING / WATSON #56
Machine ID
WATSON #56 BEARINGS FRONT END (S/N K-853-2)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1723531

Area
TWINNING / WATSON #57
Machine ID
WATSON #57 BEARINGS BACK END (S/N K-777-2)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1839078

Area
TWINNING / WATSON #57
Machine ID
WATSON #57 BEARINGS FRONT END (S/N K-777-2)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1681121

Area
TWINNING / WATSON #58
Machine ID
WATSON #58 BEARINGS BACK END (S/N K-853-4)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1861350

Area
TWINNING / WATSON #58
Machine ID
WATSON #58 BEARINGS FRONT END (S/N K-853-4)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1723537

Area
TWINNING / WATSON #59
Machine ID
WATSON #59 BEARINGS BACK END (S/N K-777-1)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1839074

Area
TWINNING / WATSON #59
Machine ID
WATSON #59 BEARINGS FRONT END (S/N K-777-1)
Component
Bearing
Make/Model
WATSON NB-560L/R



Latest sample tracking label




EID:1749501

Area
TWINNING / WATSON #61
Machine ID
WATSON #61 BEARINGS BACK END (S/N K-922-2)
Component
Bearing
Make/Model
WATSON NB-560L/R



*Latest sample
tracking label*



EID:1749498

Area
TWINNING / WATSON #61
Machine ID
WATSON #61 BEARINGS FRONT END (S/N K-922-2)
Component
Bearing
Make/Model
WATSON NB-560L/R



*Latest sample
tracking label*