



SAMPLE SUBMISSION FORM

Oil Analysis Laboratories

501 Madison Avenue	C8-1175 Appleby Line
Cary, NC 27513	Burlington, ON L7L 5H9
USA	CANADA
1-800-237-1369	1-800-268-2131
(919) 379-4102	(905) 569-8600
Fax (919) 379-4050	Fax (905) 569-8605

WEARCHECK sample kits will be replaced with unused kits if defective in manufacture, labeling, or packaging, or if lost by us or any associate company even though by negligence or other fault.

WEARCHECK shall not be liable or responsible for the future performance or failure of any engine, piece of equipment or material involved in any test or sample. The Company makes no warranties, representations, or guaranties with respect to the performance of any such engine, piece of equipment, or material.

NOTE 1: For sample identification, please ensure that you either print labels and place on the sample bottle or that you label the sample cap with the reference number (*Label) shown below.

NOTE 2: Please attach 2 Sample Information Forms (SIFs) as proof of payment for these analysis.

Shipping Info

Shipped Via: UPS - Standard
 Tracking Number: 1z1F4t1b0321684051
 Shipped On: 03/27/2024
 Submitted By: MIKE SEABURY [HEXION - MOREAU PLANT]

SAMPLING INSTRUCTIONS AND PRECAUTIONS

For best results we suggest the following precautions when taking the sample.

INSTRUCTIONS FOR TAKING SAMPLE - the SAMPLE should not be taken MORE THAN 30 MINUTES after shutdown, and the oil should have been in service for at least 10 hours or 500 miles, before the oil can accurately reflect wear conditions. **AVOID CONTAMINATION OF THE SAMPLE** - Clean around the drain plug before draining. Remove the drain, and when about half the oil has run out, catch the sample by inserting the bottle into the oil stream. The bottle should be at least 3/4 filled. Do not remove the bottle cap until you are ready to take the sample, and recap the bottle immediately after filling. Take care not to confuse samples from different units. Or, remove sample with a suction pump by inserting the siphon tube down the dipstick tube or into the sump/reservoir. The siphon tube must be clean by either replacement or rinsing with a solvent and drying. Do not rinse with gasoline or diesel fuel. Or, Engines with sample ports (i.e. gauge plugs, probalizer mini-plugs), follow the specific instructions pertaining to the sampling device purchased.

HEXION - MOREAU PLANT



*Label : 465852
 Sample Number : PLS0000576
 Test Package : IND 2
 Sample Date : 03/27/2024

Machine Id **B-1A (S/N LR01-32631)**
 Component Compressor
 Fluid ROYAL PURPLE SYNFILM 100 (23 GAL)

Machine Age :
 Fluid Age :
 Filter Age :
 Fluid Maintenance : Not Changd
 Filter Maintenance :



*Label : 465851
 Sample Number : PLS0000575
 Test Package : IND 2
 Sample Date : 03/27/2024

Machine Id **B-1B (S/N LR97-640)**
 Component Compressor
 Fluid ROYAL PURPLE SYNFILM GT 100 (23 GAL)

Machine Age :
 Fluid Age :
 Filter Age :
 Fluid Maintenance : Not Changd
 Filter Maintenance :