



SAMPLE SUBMISSION FORM

Oil Analysis Laboratories

501 Madison Avenue Cary, NC 27513 USA 1-800-237-1369 (919) 379-4102 Fax (919) 379-4050	C8-1175 Appleby Line Burlington, ON L7L 5H9 CANADA 1-800-268-2131 (905) 569-8600 Fax (905) 569-8605
---	--

WEARCHECK sample kits will be replaced with unused kits if defective in manufacture, labeling, or packaging, or if lost by us or any associate company even though by negligence or other fault.

WEARCHECK shall not be liable or responsible for the future performance or failure of any engine, piece of equipment or material involved in any test or sample. The Company makes no warranties, representations, or guaranties with respect to the performance of any such engine, piece of equipment, or material.

NOTE 1: For sample identification, please ensure that you either print labels and place on the sample bottle or that you label the sample cap with the reference number (*Label) shown below.

NOTE 2: Please attach 4 Sample Information Forms (SIFs) as proof of payment for these analysis.

Shipping Info

Shipped Via:
Tracking Number:
Shipped On:
Submitted By: BOBBY LUCKY [WARRIOR TRACTOR AND EQUIPMENT - HUN]

SAMPLING INSTRUCTIONS AND PRECAUTIONS

For best results we suggest the following precautions when taking the sample.

INSTRUCTIONS FOR TAKING SAMPLE - the SAMPLE should not be taken MORE THAN 30 MINUTES after shutdown, and the oil should have been in service for at least 10 hours or 500 miles, before the oil can accurately reflect wear conditions. AVOID CONTAMINATION OF THE SAMPLE - Clean around the drain plug before draining. Remove the drain, and when about half the oil has run out, catch the sample by inserting the bottle into the oil stream. The bottle should be at least 3/4 filled. Do not remove the bottle cap until you are ready to take the sample, and recap the bottle immediately after filling. Take care not to confuse samples from different units. Or, remove sample with a suction pump by inserting the siphon tube down the dipstick tube or into the sump/reservoir. The siphon tube must be clean by either replacement or rinsing with a solvent and drying. Do not rinse with gasoline or diesel fuel. Or, Engines with sample ports (i.e. gauge plugs, probalizer mini-plugs), follow the specific instructions pertaining to the sampling device purchased.

WARRIOR TRACTOR AND EQUIPMENT - HUNTSVILLE



*Label : 501057
Sample Number : WE0007660
Test Package : CONST
Sample Date : 06/17/2024

Machine Id JOHN DEERE 750L 1T0750LXLNF432235
Component Right Outer Final Drive
Fluid JOHN DEERE HY-GARD HYD/TRANS (2 GAL)

Machine Age : 955.0
Fluid Age : 955.0
Filter Age : 955.0
Fluid Maintenance : Changed
Filter Maintenance : None



*Label : 501064
Sample Number : WE0007655
Test Package : CONST
Sample Date : 06/17/2024

Machine Id JOHN DEERE 750L 1T0750LXLNF432235
Component Right Inner Final Drive
Fluid JOHN DEERE HY-GARD HYD/TRANS (2 GAL)

Machine Age : 955.0
Fluid Age : 955.0
Filter Age : 955.0
Fluid Maintenance : Changed
Filter Maintenance : None



*Label : 501069
Sample Number : WE0007664
Test Package : CONST
Sample Date : 06/17/2024

Machine Id JOHN DEERE 750L 1T0750LXLNF432235
Component Left Inner Final Drive
Fluid JOHN DEERE HY-GARD HYD/TRANS (2 GAL)

Machine Age : 955.0
Fluid Age : 955.0
Filter Age : 955.0
Fluid Maintenance : Changed
Filter Maintenance : None



*Label : 501071
Sample Number : WE0007622
Test Package : CONST
Sample Date : 06/17/2024

Machine Id JOHN DEERE 750L 1T0750LXLNF432235
Component Left Outer Final Drive
Fluid JOHN DEERE HY-GARD HYD/TRANS (2 GAL)

Machine Age : 955.0
Fluid Age : 955.0
Filter Age : 955.0
Fluid Maintenance : Changed
Filter Maintenance : None