

#### Machine Id JOHN DEERE 470 P 1FF470PAAPF000540 Component Swing Drive Fluid JOHN DEERE GL-5 80W90 (3 GAL)

# RECOMMENDATION

Resample at the next service interval to monitor. ( Customer Sample Comment: PF000540 )

### **WEAR**

All component wear rates are normal.

\_\_\_\_\_

## **CONTAMINATION**

There is no indication of any contamination in the oil.

# **FLUID CONDITION**


The condition of the oil is acceptable for the time in service.

Test	UOM	Method	Limit/Abn	Current	History1	History2
Sample Number		Client Info		JR0206002		
Sample Date		Client Info		09 May 2024		
Machine Age	hrs	Client Info		485		
Oil Age	hrs	Client Info		485		
Filter Age	hrs	Client Info		0		
Oil Changed		Client Info		Not Changd		
Filter Changed		Client Info		Not Changd		
Sample Status				NORMAL		
PQ		ASTM D8184		25		
Iron	ppm	ASTM D5185m	>151	73		
Chromium	ppm	ASTM D5185m	>11	1		
Nickel	ppm	ASTM D5185m	>10	0		
Titanium	ppm	ASTM D5185m		<1		
Silver	ppm	ASTM D5185m		0		
Aluminum	ppm	ASTM D5185m	>21	2		
Lead	ppm	ASTM D5185m	>51	<1		
Copper	ppm	ASTM D5185m	>51	1		
Tin	ppm	ASTM D5185m	>10	<1		
Vanadium	ppm	ASTM D5185m		<1		
White Metal	scalar	*Visual	NONE	NONE		
Yellow Metal	scalar	*Visual	NONE	NONE		
Silicon	ppm	ASTM D5185m	>31	18		
Potassium	ppm	ASTM D5185m	>20	3		
Water	ррпп	WC Method	>0.1	NEG		
Silt	scalar	*Visual	NONE	NONE		
Debris	scalar	*Visual	NONE	NONE		
Sand/Dirt	scalar	*Visual	NONE	NONE		
Appearance	scalar	*Visual	NORML	NORML		
Odor	scalar	*Visual	NORML	NORML		
Emulsified Water	scalar	*Visual	>0.1	NEG		
			20.1			
Sodium	ppm	ASTM D5185m	>51	2		
Boron	ppm	ASTM D5185m		80		
Barium	ppm	ASTM D5185m		2		
Molybdenum	ppm	ASTM D5185m		<1		
Manganese	ppm	ASTM D5185m		2		
Magnesium	ppm	ASTM D5185m		5		
Calcium	ppm	ASTM D5185m		94		
Phosphorus	ppm	ASTM D5185m		555		
Zinc	ppm	ASTM D5185m		37		
Sulfur	ppm	ASTM D5185m		15245		
Visc @ 40°C	cSt	ASTM D445		169		
-						

Report Id: CARCHAJR [WUSCAR] 06175788 (Generated: 05/14/2024 18:09:39) Rev: 1

Submitted By: Mike Young - CHARLOTTE SHOP





Submitted By: Mike Young - CHARLOTTE SHOP Page 2 of 2