LABORATORY ANALYSIS

Department Equipment No.

REYLAM - DIECAST PROTECH02 IHS ANNEAL QUENCH CELL 2 TANK 2 (X0077)

Quenching Fluid

Add make up dilution of 50:1 ENGINEERED

LUBRICANTS ENCOOL SOL-6465GF-ND-XL-

RO lean dilution until reaching recommended

reading for this reservoir is 3.02. Leaning the

amine levels to more acceptable ranges.{not

contamination in the quenching fluid. Ratio is slightly strong. Total amine content is out of

range. Tertiary amine content is out of range. Primary amine content is out of range. Alkaline

dilution of 10. The desired refractometer

dilution will lower the alkaline reserve and

applicable} There is no indication of any

Reserve is excessively high.

Oil Type

DIAGNOSIS

System

ENGINEERED LUBRICANTS ENCOOL SOL-6465GF-ND-XL-RO (--- GAL)



Customer Id: MOTMCA Sample No.: EN23100655 Lab Number: 23100655 Test Package: TEST



To manage this report scan the QR code

To discuss the diagnosis or test data: Brian Klutenkamper +1 (314)872-9540 <u>bklutenkamper@englube.com</u>

To change component or sample information: Tracy Weaks +1 (314)872-9540 tweaks@englube.com





Tel: 1-800-876-0008 info@englube.com COPELAND (MHDS)

6001 S. 35TH STREET, SUITE D"" REYNOSA, ZZ

Contact: GERARDO GUERRERO francisco.castillo@Copeland.com T: E:





