LABORATORY ANALYSIS

Department

Equipment No.

DIAGNOSIS

REYLAM - TOOL ROOM GRINDTR04 LINEAR GRINDER (X0038)

Grinding Fluid

System Oil Type

ENGINEERED LUBRICANTS ENCOOL SOL-6465GF-ND-XL-RO (--- GAL)

{not applicable} There is no indication of any contamination in the grinding fluid. The condition of the grinding fluid is suitable for service.

SAMPLE INFOR	MATIO	N			
Lab Number Date of Sample Oil Added		New (Typical)	2312-00145 28 Nov 2023 UNK	2310-00666 10 Oct 2023 UNK	2309-00670 14 Sep 2023 UNK
Last Drain Date			UNK		
Months on Sample			39.0	37.4	36.6
Last Filter Service					
Sample Point					
Sample Status			NORMAL	ABNORMAL	ABNORMAL
RATIO PER REF	RACT	OMETER			
Refract. Reading			2.7	2.2	1.6
Refract. Model			DIGITAL	DIGITAL	DIGITAL
Refract. Ratio	oil:water		10:1	13:1	1 8:1
PH (ASTM E-70)					
рН	Scale 0-14		8.9	8.8	8.7
Ratio Rec`d	oil:water		AS REC'D	AS REC'D	AS REC'D
HARDNESS (MG	à/L CA(CO3)			
Hardness (CaCO3)	mg/L		169.6	14.1	14.1
Grains			10.0	<1.0	<1.0
CIC CORROSIO	N				
CIC Dilution			AS REC'D	AS REC'D	AS REC'D
CIC Corrosion	%		0.0	0.0	0.0
BACTERIA COU	NT (CL	ASS RANG	ie 0 to 6)		
Bacteria Class	Scale 0-6		0	1	1
FUNGUS COUN	T (CLA	SS RANGE	S: YEAST 0 TO	4/MOLD 0 TO 3)	
Yeast Class	Scale 0-4		0	<u> </u>	0
Mold Class	Scale 0-3		0	0	0
CONTAMINATIO	N				
Water			NEG	NEG	NEG

Customer Id: MOTMCA Sample No.: EN23120145 Lab Number: 23120145 Test Package: TEST



To manage this report scan the QR code

To discuss the diagnosis or test data: Brian Klutenkamper +1 (314)872-9540 <u>bklutenkamper@englube.com</u>

To change component or sample information: Tracy Weaks +1 (314)872-9540 tweaks@englube.com



Tel: 1-800-876-0008 info@englube.com COPELAND (MHDS)

6001 S. 35TH STREET, SUITE D"" REYNOSA, ZZ US

Contact: GERARDO GUERRERO francisco.castillo@Copeland.com T: F:



FUEL REPORT