


EAST SYSTEM

Customer: PTRHTF10182	System Information	Sample Information
American Cast Iron Pipe Co.	System Volume: 5875 gal	Lab No: 02335526
1501 31st Avenue North	Bulk Operating Temp: 540F / 282C	Analyst: Jake Finn
Birmingham, AL 35207 USA	Heating Source:	Sample Date: 01/16/20
Attn: Jeremy Mowry	Blanket:	Received Date: 02/03/20
Tel: (205)325-7905	Fluid: PETRO CANADA PETRO-THERM	Completed: 02/18/20
E-Mail: jmowry@american-usa.com	Make: WUERZ	Jake Finn
		iake.finn@petrocanadalsp.com


Recommendation: Oil is suitable for continued use. Please resubmit for testing in 12 months.

Comments: No abnormalities noted.

Sample Date	Received Date	Fluid Age	Sample Location	Flash Point (COC)	Water (KF)	Viscosity (40°C)	Acid Number	Solids	GCD 10%	GCD 50%	GCD 90%	GCD % < 335°C
	mm/dd/yy			°F/°C	ppm	cSt	mg/KOH/ g	%wt	°F/°C	°F/°C	°F/°C	%
01/16/20	02/03/20	12y		450 / 232	8.0	35.9	0.066	0.062	711 / 377	799 / 426	890 / 477	0.00
07/23/18	08/16/18	11y	PUMP OUTLET	430 / 221	2.2	35.4	0.030	0.025	717 / 381	794 / 424	877 / 469	0.00
02/16/18	05/24/18	0y			29.0	35.3	0.04	0.058	711 / 377	799 / 426	909 / 487	0.00
01/29/17	05/24/18	0y			21.2	35.7	0.03	0.037	708 / 376	778 / 414	871 / 466	0.00
07/02/14	07/22/14	7у	PUMP INLET	441 / 227	16.7	35.8	0.02	0.119	713 / 378	808 / 431	899 / 482	0.17







Historical Comments

07/23/18	Fluid is suitable for continued use. (GCD) 90% Distillation Point is marginally low. 'Venting' the system could bring this value up to normal. Light debris noticed by the lab. Please change any system filters and/or filter the system fluid safely during any shutdowns with a portable kidney-loop filtration system.
02/16/18	Fluid is suitable for continued use. Please re-submit annual sample of Petro-therm in May 2019. During a safe shutdown opportunity the fluid can be filtered with a kidney-loop filtration system to clean up any contamination. If system has any filters, please schedule them to be changed.Light Debris noticed in sample of fluid
01/29/17	Fluid is suitable for continued use. 'Venting' the system may improve the 90% distillation point. Changing system filters or filtering fluid with a kidney loop system may reduce any 'debris' found in sample. Please include the age of the fluid and the age of the heat transfer system on next year's label. Re-submit fluid sample in May 2019Light debris seen in fluid sample. (GCD) 90% Distillation Point is abnormally low.
07/02/14	The oil is still showing results that are normal and close to fresh oil. Contamination is minimal. Re-sample same time next year or before a maintenance shut down.

Petro-Canada makes no representation or warranty of any kind, either express or implied, as to the accuracy or completeness of the analysis and assumes no responsibility and shall have no liability whatsoever with respect to such analysis, or a party's use of it. Petro-Canada is a division of HollyFrontier Corporation.