



Attn: Eric Foote Tel: x: E-Mail: eric foote@tamko.com Bulk Operating Temp: 430F / 221C Heating Source: Blanket: Fluid: PETRO CANADA CALFLO HTF Make: Heat Exchanger And T Lab No: 02405481 Analyst: Jake Finn Sample Date: 02/12/21 Received Date: 02/23/21 Completed: 03/29/21 Jake Finn jake.finn@hollyfrontier.com

Recommendation: Overall the sample indicates this system fluid is in excellent condition and suitable for continued use. All sample test results came back normal, and (GCD) 90% distillation point has improved from last year. Although the acid number is normal and was not flagged, there was an increase from 0.109 to 0.20. This is not anything to be immediately concerned about but will be monitored at the next sample interval. Please resample and submit for testing in one year

Comments: N/A

Sample Date	Received Date	Fluid Age	Sample Location	Flash Point (COC)	Water (KF)	Viscosity (40°C)	Acid Number	Solids	GCD 10%	GCD 50%	GCD 90%	GCD % < 335°C
	mm/dd/yy			°F/°C	ppm	cSt	mg/KOH/ g	%wt	°F/°C	°F/°C	°F/°C	%
02/12/21	02/23/21	0.0m		441 / 227	7.3	35.1	0.20	0.063	721 / 383	812 / 433	907 / 486	0.87
01/13/20	01/21/20	0.0m	PORT	414 / 212	16.2	35.4	0.109	0.068	729 / 387	798 / 426	886 / 475	2.36
10/08/19	10/15/19	0.0m		424 / 218	9.2	35.2	0.132	0.081	741 / 394	830 / 443	924 / 496	0.00
01/08/19	01/17/19	13.0m		435 / 224	10.1	35.5	0.065	0.077	687 / 364	782 / 417	880 / 471	2.53
06/28/18	07/09/18	0.0m	PORT	446 / 230	13.8	35.4	0.07	0.023	724 / 385	809 / 432	910 / 488	0.50





## 

## Historical Comments

2

0ct2/17

Nov1/17

Feb15/18 Jun28/18 Jan 8/19 -

0ct8/19

Feb12/21

Jan 13/20

01/13/20	Oil is suitable for continued use. Venting system is recommended to remove low-boilers and improve distillation values to desired levels. Please resubmit sample in 12 months. (GCD) 90% Distillation Point is marginally low. Low initial boiling point indicates low boilers may be present in oil. Very lite sand/dirt detected by lab. NOTE: The color of the oil is darker then previous samples.
10/08/19	Oil is suitable for continued use. Please resubmit sample in one year.(GCD) 10% Distillation Point is marginally high. (GCD) 90% Distillation point has improved compared to previous sample.
01/08/19	Venting' system fluid may increase the distillation point values to desired levels. Fluid is suitable for continued use, please resubmit sample in December 2019.(GCD) 90% Distillation Point is abnormally low.
06/28/18	Fluid is suitable for continued use. Please re-submit next sample in June 2019Some very light debris was noticed. Change any system filters regularly or tighten up the micron levels for a cleaner fluid. This fluid can be polished using a 2-stage kidney loop system safely during any shutdown periods.

Petro-Canada makes no representation or warranty of any kind, either express or implied, as to the accuracy or completeness of the analysis and assumes no responsibility and shall have no liability whatsoever with respect to such analysis, or a party's use of it. Petro-Canada is a division of HollyFrontier Corporation.

200°C

150°C

100°C

2,000

0

Time (min)

21 25 25 26 28 28 28 28 28

5 6 11 11