## LIEBHERR

## **CONSTRUCTION EQUIPMENT**

### LIEBHERR LH60M 147037-1217 - Splitter Box

Sample No: LH0131744

Oil Type: PETRO CANADA TRAXON 75W90 SYNTHETIC

<u> </u>					
SAMP	LE INFOR	MATION			
Sample Number		LH0131744	LH0271330		
Sample Date		03 Feb 2024	31 Oct 2023		
Machine Hours		2067	1062		
Oil Hours		0	0		
Oil Changed		Changed	Changed		
Sample Status		NORMAL	NORMAL		
OIL CONDITION					
Visc @ 40°C	cSt	<b>107</b>	O 141		

CONTAMINATION						
Water	%	NEG	NEG			
Silicon	ppm	<b>0</b> <1	<b>3</b>			
Sodium	ppm	<b>2</b>	<b>3</b>			
Potassium	ppm	<b>0</b> 1	O <1			

<b>(A)</b>				
₩ WEA	R METALS			
Iron	ppm	<b>12</b>	O 14	 
Copper	ppm	<b>○</b> <1	O <1	 
Lead	ppm	<b>0</b>	O <1	 
Tin	ppm	<b>0</b>	0	 
Aluminum	ppm	<b>○</b> <1	O <1	 
Chromium	ppm	<b>0</b>	0	 
Molybdenum	ppm	<b>0</b>	O 0	 
Nickel	ppm	<b>0</b>	0	 
Titanium	ppm	0	0	 
Silver	ppm	0	<1	 
Manganese	ppm	<b>0</b>	O 0	 
Vanadium	ppm	0	0	 

variaulum	ppiii	U	U			
ADDITIVES						
Calcium	ppm	<b>14</b>	O 14			
Magnesium	ppm	<b>1</b>	O 2			
Zinc	ppm	<b>15</b>	<b>18</b>			
Phosphorus	ppm	<b>1299</b>	<b>1397</b>			
Barium	ppm	<b>0</b>	O <1			
Boron	ppm	<b>227</b>	<b>119</b>			



STELLA JONES INC
25 BRAID ST
NEW WESTMINSTER, BC
CA V3L 3P2
Contact: Richard Vogel
rvogel@stella-jones.com

T: (604)999-9220 F: (604)526-8597

#### Diagnosis

Resample at the next service interval to monitor. All component wear rates are normal. There is no indication of any contamination in the oil. The condition of the oil is acceptable for the time in service.

Depot:STE25NEWUnique No:5722893Signed:Wes DavisReport Date:06 Feb 2024

# LIEBHERR

CONSTRUCTION EQUIPMENT





#### **GRAPHS**

