# LIEBHERR

### **CONSTRUCTION EQUIPMENT**

### LIEBHERR LH60M 146891-1217 - Splitter Box

**Sample No:** LH0271812

Oil Type: PETRO CANADA TRAXON 75W90 SYNTHETIC

<b>5</b>				
U San	nple Info	rmation		
Sample Number	r	LH0271812	LH	 
Sample Date		24 May 2024	22 Dec 2023	 
Machine Hours		1000	519	 
Oil Hours		0	0	 
Oil Changed		Changed	Changed	 
Sample Status		NORMAL	NORMAL	 
Oil	Conditio	n		
Visc @ 40°C	cSt	<b>122</b>	191	 
Con	taminat	ion		
Mator	0/	NEG	NEG	

Conta	mination			
Water	%	NEG	NEG	 
Silicon	ppm	<b>0</b> <1	O <1	 
Sodium	ppm	<b>3</b>	<b>4</b>	 
Potassium	ppm	<b>2</b>	<b>3</b>	 
(Ö Wegr	Metals			

Wed	ır Metals			
Iron	ppm	<b>14</b>	O 14	 
Copper	ppm	<b>○</b> <1	O 1	 
Lead	ppm	<b></b> <1	O <1	 
Tin	ppm	<b>0</b>	O 0	 
Aluminum	ppm	<b></b> <1	O <1	 
Chromium	ppm	<b>0</b>	0	 
Molybdenum	ppm	<b>0</b>	O 0	 
Nickel	ppm	<b>○</b> <1	O <1	 
Titanium	ppm	0	0	 
Silver	ppm	0	0	 
Manganese	ppm	<b></b> <1	<b></b> <1	 
Vanadium	ppm	0	0	 

Addi	<b>Li</b> vos			
Calcium	ppm	<b>14</b>	<b>1</b> 5	 
Magnesium	ppm	<b>2</b>	O 2	 
Zinc	ppm	<b>22</b>	19	 
Phosphorus	ppm	<b>1395</b>	O 1539	 
Barium	ppm	<b>○</b> <1	O 0	 
Boron	ppm	<b>182</b>	1	 



#### RICHMOND STEEL RECYCLING

11760 MITCHELL ROAD RICHMOND, BC CA V6V 1V8

Contact: Aaron Kaetler AKaetler@richmondsteel.ca

T:

F: (604)324-8617

#### Diagnosis

Resample at the next service interval to monitor. All component wear rates are normal. There is no indication of any contamination in the oil. The condition of the oil is acceptable for the time in service.

Depot:RIC117RICUnique No:5800198Signed:Wes DavisReport Date:18 Jun 2024

## LIEBHERR

CONSTRUCTION EQUIPMENT





#### **Graphs**

