LIEBHERR

CONSTRUCTION EQUIPMENT

LIEBHERR LH50 1216-140094 - Splitter Box

Sample No: LH06000825

Oil Type: LIEBHERR GEAR BASIC 90 LS

| 5 | | | | | | |
|-------------------|--|-------------|--|--|--|--|
| SAMPLEINFORMATION | | | | | | |
| Sample Number | | LH06000825 | | | | |
| Sample Date | | 25 Oct 2023 | | | | |
| Machine Hours | | 2263 | | | | |
| Oil Hours | | 500 | | | | |
| Oil Changed | | Changed | | | | |
| Sample Status | | NORMAL | | | | |
| | | | | | | |

| OIL CONDITION | | | | | | | |
|---------------|-----|------------|--|--|--|--|--|
| Visc @ 40°C | cSt | 193 | | | | | |
| | | | | | | | |

| ** | | | | | | | |
|---------------|-----|-------------|--|--|--|--|--|
| CONTAMINATION | | | | | | | |
| Silicon | ppm | O <1 | | | | | |
| Sodium | ppm | 2 | | | | | |
| Potassium | ppm | 2 | | | | | |
| | | | | | | | |

| WEAR METALS | | | | | | |
|-------------|-----|-------------|--|--|--|--|
| Iron | ppm | 41 | | | | |
| Copper | ppm | 3 | | | | |
| Lead | ppm | 0 | | | | |
| Tin | ppm | 0 | | | | |
| Aluminum | ppm | 2 | | | | |
| Chromium | ppm | ○ <1 | | | | |
| Molybdenum | ppm | 0 | | | | |
| Nickel | ppm | 0 | | | | |
| Titanium | ppm | 0 | | | | |
| Silver | ppm | 0 | | | | |
| Manganese | ppm | ○ <1 | | | | |
| Vanadium | ppm | 0 | | | | |

| ADDITIVES | | | | | | |
|------------|-----|-------------|--|--|--|--|
| Calcium | ppm | 33 | | | | |
| Magnesium | ppm | 3 | | | | |
| Zinc | ppm | 17 | | | | |
| Phosphorus | ppm | 1541 | | | | |
| Barium | ppm | 5 | | | | |
| Boron | ppm | 0 | | | | |



RECO EQUIPMENT INC.

1615 JP HENESSY DRIVE LAVERGNE, TN US 37086

Contact: KEN FISCHER

T: (615)610-7326

F:

Diagnosis

Resample at the next service interval to monitor. All component wear rates are normal. There is no indication of any contamination in the oil. The condition of the oil is acceptable for the time in service.

Depot:RECLAVUnique No:10729185Signed:Sean FeltonReport Date:09 Nov 2023

LIEBHERR







GRAPHS

