LIEBHERR

CONSTRUCTION EQUIPMENT

LIEBHERR L550 059181-1756 - Front Differential

Sample No: LH0245750

Oil Type: SHELL SPIRAX HD 80W90

_					
INFORMATION SUR L'ÉCHANTILLON					
Numéro d'échant.		LH0245750	LH0221709		
Date d'échant.		27 Sep 2023	05 Oct 2022		
Heures de la Machine		3336	1026		
		0	0		
Heures de l'huile		-			
Huile changée		Changed	Changed NORMAL		
Statut de l'echant. ABNORMAL NORMAL					
• •					
ETATI	D'HUILE				
Visc 40°C	cSt	177	O 53.9		
-1			0 11 1		
CONTAMINATION					
CONT	AMINAII	JN			
Silicium	ppm	8	O 10		
Sodium	ppm	8	19		
Potassium	ppm	0	O <1		
MéTAUX D'USURE					
			0.00		
Fer	ppm	230	○ 98		
Cuivre	ppm	52	O 39		
Plomb	ppm	2	01		
Étain	ppm	0 2	01		
Aluminium	ppm	2	O 3		
Chrome	ppm	2	0 1	***	***
Molybdène	ppm	32	O 14		***
Nickel	ppm	01	02		
Titane	ppm	0	<1		
Argent	ppm	<1	0		
Manganèse	ppm	25	41	***	***
Vanadium	ppm	0	0		
ADDI					
ADDI'	ΓIFS				
Calcium	ppm	349	3697		
Magnésium	ppm	○ 6	0 10		
Zinc	ppm	103	1409		
Phosphore	ppm	2130	O 1243		
Baryum	ppm	O <1	0 <1		
Bore	ppm	8	106		
_ 5.0	F P · · ·				



AV Terrace Bay Inc.

21 Mill Rd. Terrace Bay, ON CA P0T 2W0

Contact: Naqshe Iqbal naqshe.iqbal@adityabirla.com

T: (807)823-0761

F:

Diagnostic

The oil change at the time of sampling has been noted. Confirm the source of the lubricant being utilized for top-up/fill. We recommend an early resample to monitor this condition. Copper ppm levels are abnormal. Thrust washer and/or bearing/bushing wear is indicated. There is no indication of any contamination in the oil. Additive levels indicate the addition of a different brand, or type of oil. The oil is no longer serviceable as a result of the abnormal and/or severe wear.

Depot:AVTTERUnique No:5658030Signed:Kevin MarsonReport Date:16 Oct 2023

LIEBHERR







GRAPHS

