
PROBLEM SUMMARY




B360 DIAGNOSTICS

Machine Id **160130**

Component Gearbox Fluid PETRO CANADA TURBOFLO R&O 150 (--- GAL)

COMPONENT CONDITION SUMMARY



RECOMMENDATION

We recommend an early resample to monitor this condition. NOTE: Please provide information regarding reservoir capacity, filter type and micron rating with next sample.

PROBLEMATIC TEST RESULTS									
Sample Status				ATTENTION	NORMAL				
Lead	ppm	ASTM D5185(m)	>100	<u> </u>	19				

Customer Id: CANDRY Sample No.: PC0069838 Lab Number: 02579524 Test Package: IND 2



To manage this report scan the QR code

To discuss the diagnosis or test data: Kevin Marson +1 (289)291-4644 x4644 Kevin.Marson@wearcheck.com

To change component or sample information: Gloria Gonzalez +1 (289)291-4643 x4643 <u>gloria.gonzalez@wearcheck.com</u>

RECOMMENDED ACTIONS							
Action	Status	Date	Done By	Description			
Resample			?	We recommend an early resample to monitor this condition.			
Information Required			?	NOTE: Please provide information regarding reservoir capacity, filter type and micron rating with next sample.			

HISTORICAL DIAGNOSIS



16 Aug 2023 Diag: Wes Davis

Resample at the next service interval to monitor. NOTE: Please provide information regarding reservoir capacity, filter type and micron rating with next sample.All component wear rates are normal. There is no indication of any contamination in the oil. The AN level is acceptable for this fluid. The condition of the oil is suitable for further service.





OIL ANALYSIS REPORT

Sample Rating Trend

WEAR



160130 Component

Gearbox

Fluid PETRO CANADA TURBOFLO R&O 150 (--- GAL)

DIAGNOSIS

Recommendation

We recommend an early resample to monitor this condition. NOTE: Please provide information regarding reservoir capacity, filter type and micron rating with next sample.

A Wear

Lead ppm levels are noted. All other component wear rates are normal.

Contamination

There is no indication of any contamination in the oil.


Fluid Condition


The AN level is acceptable for this fluid. The condition of the oil is suitable for further service.


GAL)			Aug2023	Aug ² 023		
SAMPLE INFORI	MATION	method	limit/base	current	history1	history2
Sample Number		Client Info		PC0069838	PC0069836	
Sample Date		Client Info		16 Aug 2023	16 Aug 2023	
Machine Age	hrs	Client Info		0	0	
Oil Age	hrs	Client Info		0	0	
Oil Changed		Client Info		N/A	N/A	
Sample Status				ATTENTION	NORMAL	
WEAR METAL	S	method	limit/base	current	history1	history2
PQ		ASTM D8184*		0	0	
Iron	ppm	ASTM D5185(m)	>200	14	11	
Chromium	ppm	ASTM D5185(m)	>15	0	0	
Nickel	ppm	ASTM D5185(m)	>15	<1	<1	
Titanium	ppm	ASTM D5185(m)		0	0	
Silver	ppm	ASTM D5185(m)		0	0	
Aluminum	ppm	ASTM D5185(m)	>25	<1	<1	
Lead	ppm	ASTM D5185(m)	>100	<mark>人</mark> 67	19	
Copper	ppm	ASTM D5185(m)	>200	6	2	
Tin	ppm	ASTM D5185(m)	>25	<1	<1	
Antimony	ppm	ASTM D5185(m)	>5	0	0	
Vanadium	ppm	ASTM D5185(m)		0	0	
Beryllium	ppm	ASTM D5185(m)		0	0	
Cadmium	ppm	ASTM D5185(m)		0	0	
ADDITIVES		method	limit/base	current	history1	history2
Boron	ppm	ASTM D5185(m)		<1	<1	
Barium	ppm	ASTM D5185(m)		0	0	
Molybdenum	ppm	ASTM D5185(m)		0	0	
Manganese	ppm	ASTM D5185(m)		<1	<1	
Magnesium	ppm	ASTM D5185(m)		<1	<1	
Calcium	ppm	ASTM D5185(m)	0	4	4	
Phosphorus	ppm	ASTM D5185(m)	4	5	6	
Zinc	ppm	ASTM D5185(m)	0	15	5	
Sulfur	ppm	ASTM D5185(m)		3500	3503	
Lithium	ppm	ASTM D5185(m)		<1	<1	
CONTAMINAN	TS	method	limit/base	current	history1	history2
Silicon	ppm	ASTM D5185(m)	>50	1	3	
Sodium	ppm	ASTM D5185(m)		<1	<1	
Potassium	ppm	ASTM D5185(m)	>20	<1	<1	
FLUID DEGRAD		method	limit/base	current	history1	history2
Acid Number (AN)	mg KOH/g	ASTM D974*	0.18	0.07	0.07	




OIL ANALYSIS REPORT









: Kevin Marson

 Laboratory
 Test Package
 : IND 2 (Additional Tests: KV100, VI)

 To discuss this sample report, contact Customer Service at 1-800-268-2131.

 Test denoted (*) outside scope of accreditation, (m) method modified, (e) tested at external lab.

 Validity of results and interpretation are based on the sample and information as supplied.

Diagnostician

CA P8N 2Z7

T: (807)223-9838

F: (807)223-9176

Contact: Yvon St. Laurent

yvon.stlaurent@domtar.com