


# **PROBLEM SUMMARY**

KAESER SX 7 2550297 (S/N 1188)

Compressor

KAESER SIGMA (OEM) M-460 (--- GAL)



# **COMPONENT CONDITION SUMMARY**

No relevant graphs to display

## RECOMMENDATION

Oil and filter change at the time of sampling has been noted. No corrective action is recommended at this time. Resample at the next service interval to monitor. We were unable to perform a particle count due to a high concentration of particles present in this sample.

PROBLEMATIC T	EST RE	SULTS			
Sample Status				ABNORMAL	 
Debris	scalar	*Visual	NONE	▲ MODER	 

Customer Id: KAECYP Sample No.: KCP55007 Lab Number: 05924320 Test Package: IND 2

To manage this report scan the QR code

To discuss the diagnosis or test data:

Don Baldridge +1 don.b505@comcast.net

To change component or sample information: Customer Service +1 1-800-237-1369 customerservice@wearcheck.com

RECOMMENDED ACTIONS						
Action	Status	Date	Done By	Description		
Change Fluid			?	Oil and filter change at the time of sampling has been noted.		
Change Filter			?	Oil and filter change at the time of sampling has been noted.		
Alert			?	We were unable to perform a particle count due to a high concentration of particles present in this sample.		



# **OIL ANALYSIS REPORT**

Sample Rating Trend

**VIS DEBRIS** 

# KAESER SX 7 2550297 (S/N 1188)

Compressor

KAESER SIGMA (OEM) M-460 (--- GAL)

# **DIAGNOSIS**

#### Recommendation

Oil and filter change at the time of sampling has been noted. No corrective action is recommended at this time. Resample at the next service interval to monitor. We were unable to perform a particle count due to a high concentration of particles present in this sample.

#### Wear

All component wear rates are normal.

### Contamination

Moderate concentration of visible dirt/debris present in the oil.

## **Fluid Condition**

The AN level is acceptable for this fluid. The condition of the oil is suitable for further service.

		<u>-</u>		Aug2023		
SAMPLE INFORM	1ATION	method	limit/base	current	history1	history2
Sample Number		Client Info		KCP55007		
Sample Date		Client Info		09 Aug 2023		
Machine Age	hrs	Client Info		10825		
Oil Age	hrs	Client Info		2000		
Oil Changed		Client Info		Changed		
Sample Status				ABNORMAL		
WEAR METALS		method	limit/base	current	history1	history2
Iron	ppm	ASTM D5185m	>50	0		
Chromium	ppm	ASTM D5185m	>10	0		
Nickel	ppm	ASTM D5185m	>3	0		
Titanium	ppm	ASTM D5185m	>3	0		
Silver	ppm	ASTM D5185m	>2	0		
Aluminum	ppm	ASTM D5185m	>10	0		
Lead	ppm	ASTM D5185m	>10	0		
Copper	ppm	ASTM D5185m	>50	15		
Tin	ppm	ASTM D5185m	>10	0		
Vanadium	ppm	ASTM D5185m		0		
Cadmium	ppm	ASTM D5185m		0		
ADDITIVES		method	limit/base	current	history1	history2
Boron	ppm	ASTM D5185m	0	0		
Barium	ppm	ASTM D5185m	90	0		
Molybdenum	ppm	ASTM D5185m	0	0		
Manganese	ppm	ASTM D5185m		<1		
Magnesium	ppm	ASTM D5185m	100	0		
Calcium	ppm	ASTM D5185m	0	0		
Phosphorus	ppm	ASTM D5185m	0	3		
Zinc	ppm	ASTM D5185m	0	0		
Sulfur	ppm	ASTM D5185m	23500	18407		
CONTAMINANTS		method	limit/base	current	history1	history2
Silicon	ppm	ASTM D5185m	>25	15		
Sodium	ppm	ASTM D5185m		0		
Potassium	ppm	ASTM D5185m	>20	0		
Water	%	ASTM D6304	>0.05	0.004		
ppm Water	ppm	ASTM D6304	>500	45.3		
FLUID DEGRADA	TION	method	limit/base	current	history1	history2
A adal Niconala a v. (ANI)	ma I/OII/-	ACTM DODAE	1.0	0.40		


0.40

Acid Number (AN)

mg KOH/g ASTM D8045 1.0



# **OIL ANALYSIS REPORT**



: WearCheck USA - 501 Madison Ave., Cary, NC 27513

: 14 Aug 2023

: 16 Aug 2023

Received

Diagnosed





Certificate L2367

Laboratory Sample No. Lab Number

: KCP55007 : 05924320 : 10604267

**Unique Number** 

Diagnostician : Don Baldridge Test Package : IND 2 ( Additional Tests: KF, PrtCount ) To discuss this sample report, contact Customer Service at 1-800-237-1369.

\* - Denotes test methods that are outside of the ISO 17025 scope of accreditation. Statements of conformity to specifications are based on the simple acceptance decision rule (JCGM 106:2012) KAESER COMPRESSORS

11105 DANA CIRCLE CYPRESS, CA US 90630

Contact: PHILLIP CHRISTY phillip.christy@kaeser.com T: (714)893-0730

F: (714)893-0731