


PROBLEM SUMMARY




KAESER 6654657

Component

Compressor

KAESER SIGMA (OEM) M-460 (--- GAL)

COMPONENT CONDITION SUMMARY



RECOMMENDATION

There is too much water present in this sample to perform a particle count. We advise that you stop the unit and follow the water drain-off procedure for this component. We recommend an early resample in 500 hours to monitor this condition.

PROBLEMATIC TEST RESULTS											
Sample Status				SEVERE	ATTENTION						
Water	%	ASTM D6304	>0.05	2.41	0.010						
ppm Water	ppm	ASTM D6304	>500	24100	101.7						
Appearance	scalar	*Visual	NORML	▲ HAZY	NORML						
Emulsified Water	scalar	*Visual	>0.05	0.2%	NEG						

Customer Id: FLUSAC Sample No.: KCPA005129 Lab Number: 05938883 Test Package: IND 2



To manage this report scan the QR code

To discuss the diagnosis or test data:

Don Baldridge +1 don.b505@comcast.net

To change component or sample information: Customer Service +1 1-800-237-1369 customerservice@wearcheck.com

RECOMMENDED ACTIONS

There are no recommended actions for this sample.

HISTORICAL DIAGNOSIS

06 Jul 2022 Diag: Doug Bogart

ISO



No corrective action is recommended at this time. Oil and filter change at the time of sampling has been noted. Resample at the next service interval to monitor. All component wear rates are normal. There is a moderate amount of particulates present in the oil. The AN level is acceptable for this fluid. The condition of the oil is suitable for further service.





OIL ANALYSIS REPORT

KAESER 6654657

Component

Compressor

KAESER SIGMA (OEM) M-460 (--- GAL)

Sample Rating Trend



DIAGNOSIS

Recommendation

There is too much water present in this sample to perform a particle count. We advise that you stop the unit and follow the water drain-off procedure for this component. We recommend an early resample in 500 hours to monitor this condition.

All component wear rates are normal.

Contamination

There is a high concentration of water present in the oil.


Fluid Condition

The AN level is acceptable for this fluid.

			Jul2022	Aug2023		
SAMPLE INFORM	MATION	method	limit/base	current	history1	history2
Sample Number		Client Info		KCPA005129	KCP51547	
Sample Date		Client Info		16 Aug 2023	06 Jul 2022	
Machine Age	hrs	Client Info		15071	10932	
Oil Age	hrs	Client Info		0	0	
Oil Changed		Client Info		N/A	Changed	
Sample Status				SEVERE	ATTENTION	
WEAR METALS		method	limit/base	current	history1	history2
Iron	ppm	ASTM D5185m	>50	0	0	
Chromium	ppm	ASTM D5185m	>10	0	0	
Nickel	ppm	ASTM D5185m	>3	0	0	
Titanium	ppm	ASTM D5185m	>3	0	0	
Silver	ppm	ASTM D5185m	>2	0	0	
Aluminum	ppm	ASTM D5185m	>10	1	<1	
Lead	ppm	ASTM D5185m	>10	0	0	
Copper	ppm	ASTM D5185m	>50	14	11	
Tin	ppm	ASTM D5185m	>10	<1	0	
Vanadium	ppm	ASTM D5185m		0	0	
Cadmium	ppm	ASTM D5185m		0	0	
ADDITIVES		method	limit/base	current	history1	history2
Boron	ppm	ASTM D5185m	0	0	0	
Barium	ppm	ASTM D5185m	90	0	0	
Molybdenum	ppm	ASTM D5185m	0	0	0	
Manganese	ppm	ASTM D5185m		0	0	
Magnesium	ppm	ASTM D5185m	100	2	0	
Calcium	ppm	ASTM D5185m	0	<1	0	
Phosphorus	ppm	ASTM D5185m	0	4	5	
Zinc	ppm	ASTM D5185m	0	70	12	
Sulfur	ppm	ASTM D5185m	23500	20950	22029	
CONTAMINANTS	3	method	limit/base	current	history1	history2
Silicon	ppm	ASTM D5185m	>25	10	10	
Sodium	ppm	ASTM D5185m		<1	0	
Potassium	ppm	ASTM D5185m	>20	0	0	
Water	%	ASTM D6304	>0.05	2.41	0.010	
ppm Water	ppm	ASTM D6304	>500	24100	101.7	
FLUID CLEANLIN	IESS	method	limit/base	current	history1	history2
Particles >4µm		ASTM D7647			5452	
Particles >6µm		ASTM D7647	>1300		<u></u> 1430	
Particles >14µm		ASTM D7647	>80		9 7	
Particles >21µm		ASTM D7647	>20		17	
Particles >38µm		ASTM D7647	>4		1	
Particles >71µm		ASTM D7647	>3		0	
Oil Cleanliness		ISO 4406 (c)	>/17/13		<u>^</u> 20/18/14	
FLUID DEGRADA	NOITA	method	limit/base	current	history1	history2
Acid Number (AN)	mg KOH/g	ASTM D8045	1.0	0.09	0.45	



OIL ANALYSIS REPORT







Certificate L2367

Laboratory Sample No. Lab Number Unique Number

: WearCheck USA - 501 Madison Ave., Cary, NC 27513 : KCPA005129 : 05938883

: 10629495

Received : 30 Aug 2023 : 01 Sep 2023 Diagnosed

Diagnostician : Don Baldridge

Test Package : IND 2 (Additional Tests: KF, PrtCount) To discuss this sample report, contact Customer Service at 1-800-237-1369.

* - Denotes test methods that are outside of the ISO 17025 scope of accreditation.

Statements of conformity to specifications are based on the simple acceptance decision rule (JCGM 106:2012)

FLUID TECH HYDRAUCLICS INC

8432 TIOGAWOODS DR SACRAMENTO, CA US 95828

Contact: Service Manager

T: F: