


PROBLEM SUMMARY




TKE 103653 - HEALTH & WELLNESS


Hydraulic System

NOT GIVEN (--- GAL)



COMPONENT CONDITION SUMMARY





RECOMMENDATION

We recommend that you drain the oil and perform a filter service on this component if not already done. Resample at the next service interval to monitor.

PROBLEMATIC TEST RESULTS									
Sample Status				ABNORMAL					
Particles >4µm		ASTM D7647	>5000	A 8913					
Oil Cleanliness		ISO 4406 (c)	>19/16/13	<u>^</u> 20/16/11					
Acid Number (AN)	mg KOH/g	ASTM D8045		19.74					

Customer Id: BIOELK Sample No.: BB0000376 Lab Number: 05978219 Test Package: PLANT

To manage this report scan the QR code

To discuss the diagnosis or test data: Doug Bogart +1 (800)237-1369 x4016 dougb@wearcheckusa.com

To change component or sample information: Customer Service +1 1-800-237-1369 customerservice@wearcheck.com

RECOMMENDED ACTIONS						
Action	Status	Date	Done By	Description		
Change Fluid			?	We recommend that you drain the oil and perform a filter service on this component if not already done.		
Change Filter			?	We recommend that you drain the oil and perform a filter service on this component if not already done.		

HISTORICAL DIAGNOSIS



OIL ANALYSIS REPORT

Sample Rating Trend

DEGRADATION



Machine Id

TKE 103653 - HEALTH & WELLNESS

Componen

Hydraulic System

NOT GIVEN (--- GAL)

DIAGNOSIS

Recommendation

We recommend that you drain the oil and perform a filter service on this component if not already done. Resample at the next service interval to monitor.

Wear

All component wear rates are normal.

Contamination

There is a moderate amount of silt (particulates < 14 microns in size) present in the oil.

Fluid Condition

The AN level is above the recommended limit.


				Sep2023		
SAMPLE INFORM	MATION	method	limit/base	current	history1	history2
Sample Number		Client Info		BB0000376		
Sample Date		Client Info		26 Sep 2023		
Machine Age	hrs	Client Info		0		
Oil Age	hrs	Client Info		0		
Oil Changed		Client Info		N/A		
Sample Status				ABNORMAL		
WEAR METALS		method	limit/base	current	history1	history2
Iron	ppm	ASTM D5185m	>20	4		
Chromium	ppm	ASTM D5185m	>20	0		
Nickel	ppm	ASTM D5185m	>20	0		
Titanium	ppm	ASTM D5185m		<1		
Silver	ppm	ASTM D5185m		0		
Aluminum	ppm	ASTM D5185m	>20	0		
Lead	ppm	ASTM D5185m	>20	0		
Copper	ppm	ASTM D5185m	>20	<1		
Tin	ppm	ASTM D5185m	>20	0		
Vanadium	ppm	ASTM D5185m		0		
Cadmium	ppm	ASTM D5185m		0		
ADDITIVES		method	limit/base	current	history1	history2
Boron	ppm	ASTM D5185m		0		
Barium	ppm	ASTM D5185m		1		
Molybdenum	ppm	ASTM D5185m		0		
Manganese	ppm	ASTM D5185m		0		
Magnesium	ppm	ASTM D5185m		5		
Calcium	ppm	ASTM D5185m		49		
Phosphorus	ppm	ASTM D5185m		179		
Zinc	ppm	ASTM D5185m		25		
Sulfur	ppm	ASTM D5185m		2170		
CONTAMINANTS	3	method	limit/base	current	history1	history2
Silicon	ppm	ASTM D5185m	>15	1		
Sodium	ppm	ASTM D5185m	210	1		
Potassium	ppm	ASTM D5185m	>20	0		
FLUID CLEANLIN	IESS	method	limit/base	current	history1	history2
Particles >4µm		ASTM D7647	>5000	▲ 8913		
Particles >6µm		ASTM D7647	>640	399		
Particles >14µm		ASTM D7647	>80	19		
Particles >21µm		ASTM D7647	>20	3		
Particles >38µm		ASTM D7647	>4	1		
Particles >71µm		ASTM D7647	>3	0		
Oil Cleanliness		ISO 4406 (c)	>19/16/13	△ 20/16/11		
FLUID DEGRADA	ATION	method	limit/base	current	history1	history2

Acid Number (AN) mg KOH/g ASTM D8045

19.74



OIL ANALYSIS REPORT







Certificate L2367

Laboratory Sample No. Lab Number Unique Number

: BB0000376 : 05978219 : 10695514 Test Package : PLANT

: WearCheck USA - 501 Madison Ave., Cary, NC 27513 Received : 13 Oct 2023 Diagnosed Diagnostician

: 19 Oct 2023 : Doug Bogart

To discuss this sample report, contact Customer Service at 1-800-237-1369.

* - Denotes test methods that are outside of the ISO 17025 scope of accreditation. Statements of conformity to specifications are based on the simple acceptance decision rule (JCGM 106:2012)

BioBlend - Elk Grove VIllage 1500 JARVIS AVE ELK GROVE VILLAGE, IL US 60007

Contact: DAN GABRIEL dan.gabriel@bioblend.com

T: F: