

SAMPLE SUBMISSION FORM

LIEBHERR

CONSTRUCTION EQUIPMENT



Oil Analysis Laboratories

501 Madison Avenue C8-1175 Appleby Line
 Cary, NC 27513 Burlington, ON L7L 5H9
 USA CANADA
 1-800-237-1369 1-800-268-2131
 (919) 379-4102 (905) 569-8600
 Fax (919) 379-4050 Fax (905) 569-8605

LIEBHERR sample kits will be replaced with unused kits if defective in manufacture, labeling, or packaging, or if lost by us or any associate company even though by negligence or other fault.

LIEBHERR shall not be liable or responsible for the future performance or failure of any engine, piece of equipment or material involved in any test or sample. The Company makes no warranties, representations, or guaranties with respect to the performance of any such engine, piece of equipment, or material.

NOTE 1: For sample identification, please ensure that you either print labels and place on the sample bottle or that you label the sample cap with the reference number (*Label) shown below.

NOTE 2: Please attach 13 Sample Information Forms (SIFs) as proof of payment for these analysis.

Shipping Info

Shipped Via: N/A
 Tracking Number: N/A
 Shipped On: 09/20/2023
 Submitted By: Eric Leblond [LIEBHERR CANADA LTEE]

Machine / Sample Info

Make: LIEBHERR
 Machine ID: LIEBHERR LH30M 090215-1253
 Machine Hrs: 12906.0
 Sample Date: 09/20/2023

Customer

VEOLIA-SERVICES A L'ENVIRONNEMENT
 2630, BLVD INDUSTRIEL
 CHAMBLY, QC J3L 4V2 CA
 Attn: Service Manager
 Ph: Fax:

*Label	Component	Time on Oil	Oil Maint	Filter Maint	Oil Type
397107	Transmission (Manual)		Changed		PETRO CANADA DURON UHP 5W30
397097	Transmission		Changed		NOT GIVEN
397099	Swing Drive		Changed		LIEBHERR GEAR BASIC 90 LS
397111	Front Left Wheel Hub		Changed		LIEBHERR GEAR BASIC 90 LS
397112	Front Differential		Changed		LIEBHERR GEAR BASIC 90 LS
397113	Front Right Wheel Hub		Changed		LIEBHERR GEAR BASIC 90 LS
397114	Rear Left Wheel Hub		Changed		LIEBHERR GEAR BASIC 90 LS
397115	Rear Differential		Changed		LIEBHERR GEAR BASIC 90 LS
397116	Rear Right Wheel Hub		Changed		LIEBHERR GEAR BASIC 90 LS

SAMPLING INSTRUCTIONS AND PRECAUTIONS

For best results we suggest the following precautions when taking the sample.

INSTRUCTIONS FOR TAKING SAMPLE - the SAMPLE should not be taken MORE THAN 30 MINUTES after shutdown, and the oil should have been in service for at least 10 hours or 500 miles, before the oil can accurately reflect wear conditions.
AVOID CONTAMINATION OF THE SAMPLE - Clean around the drain plug before draining. Remove the drain, and when about half the oil has run out, catch the sample by inserting the bottle into the oil stream. The bottle should be at least 3/4 filled. Do not remove the bottle cap until you are ready to take the sample, and recap the bottle immediately after filling. Take care not to confuse samples from different units.
 Or, remove sample with a suction pump by inserting the siphon tube down the dipstick tube or into the sump/reservoir. The siphon tube must be clean by either replacement or rinsing with a solvent and drying. Do not rinse with gasoline or diesel fuel.
 Or, Engines with sample ports (i.e. gauge plugs, probalizer mini-plugs), follow the specific instructions pertaining to the sampling device purchased.