

SAMPLE SUBMISSION FORM

Oil Analysis Laboratories

501 Madison Avenue Cary, NC 27513 USA

C8-1175 Appleby Line Burlington, ON L7L 5H9 **CANADA**

1-800-237-1369 (919) 379-4102 Fax (919) 379-4050

1-800-268-2131 (905) 569-8600 Fax (905) 569-8605

NOTE 1: For sample identification, please ensure that you either print labels and place on the sample bottle or that you label the sample cap with the reference number (*Label) shown below.

NOTE 2: Please attach 2 Sample Information Forms (SIFs) as proof of payment for these analysis.

WEARCHECK sample kits will be replaced with unused kits if defective in manufacture, labeling, or packaging, or if lost by us or any associate company even though by negligence or other fault.

WEARCHECK shall not be liable or responsible for the future performance or failure of any engine, piece of equipment or material involved in any test or sample. The Company makes no warranties, representations, or guaranties with respect to the performance of any such engine, piece of equipment, or material.

Shipping Info

Shipped Via:

Tracking Number:

Shipped On:

Submitted By: PATRICK ISRAEL [STEVENS AEROSPACE AND DEFENSE SYSTEMS, LLC]

SAMPLING INSTRUCTIONS AND PRECAUTIONS

For best results we suggest the following precautions when taking the sample.

INSTRUCTIONS FOR TAKING SAMPLE - the SAMPLE should not be taken MORE THAN 30 MINUTES after shutdown, and the oil should have been in service for at least 10 hours or 500 miles, before the oil can accurately reflect wear conditions. AVOID CONTAMINATION OF THE SAMPLE - Clean around the drain plug before draining. Remove the drain, and when about half the oil has run out, catch the sample by inserting the bottle into the oil stream. The bottle should be at least 3/4 filled. Do not remove the bottle cap until you are ready to take the sample, and recap the bottle immediately after filling. Take care not to confuse samples from different units,

Or, remove sample with a suction pump by inserting the siphon tube down the dipstick tube or into the sump/reservoir. The siphon tube must be clean by either replacement or rinsing with a solvent and drying. Do not rinse with gasoline or diesel fuel. Or, Engines with sample ports (i.e. gauge plugs, probalizer mini-plugs), follow the specific instructions pertaining to the sampling device purchased.

STEVENS AEROSPACE AND DEFENSE SYSTEMS, LLC

: 490663

: 490662 *Label Sample Number : GF0001696

Test Package : AVI 1

Sample Date : 05/28/2024

Label

Test Package : AVI 1

Sample Date

Component Fluid

Machine Id

BEECH 404JP (S/N LJ-1039) PRATT AND WHITNEY PT6A-20 PCE-25052 Left Turbine

BP TURBO OIL 2380 (12 QTS)

BEECH 404JP (S/N LJ-1039)

Machine Age : 9396.1 Fluid Age 9396.1

Filter Age 801.0 Fluid Maintenance : Not Changd Filter Maintenance : Not Changd

Machine Age : 9396.1 Fluid Age : 9396.1 : 801.0 Filter Age Fluid Maintenance

Sample Number : GF0001697 Machine Id PRATT AND WHITNEY PT6A-20 PCE-25056 Right Turbine Component : Not Changd : 05/28/2024 BP TURBO OIL 2380 (12 QTS) Fluid Filter Maintenance : Not Changd

Transit Id: 490662 to 490663 Page 1 of 1