

Download the App



<https://bit.ly/oilapp>



<https://bit.ly/oaplay>

Download the Oil Analysis app from the App Store or Google Play. After installation, use your WebCheck credentials to login to the app.

Take your oil samples



1

Remove the sample label from the sample form and stick to the sample bottle.



2

Take the oil sample as you normally would and re-cap the sample bottle.



3

Ensure that the cap is securely tightened and wipe any excess oil from the sample bottle.

Complete sample submission with the asset tag booklet & the app



4

Using the app, scan the QR code of the machine the sample was taken from. Remove the tracking label from the sample form and stick to the asset log booklet.



5

Next, scan the sample label, and complete the sample information and submit the sample.




1

Login to the app using your WebCheck credentials. The app will cache your machines.





2

Once logged in, click on the "Scan QR Code" button.




3

Locate the machine that was sampled in the asset tag booklet and scan that QR code. Stick the tracking label on your booklet.



4

From the list of components slide left on the component and click "+ Sample".




5

The component is selected & sample submission screen is loaded. Click the "Scan" button.



6

Scan the sample bottle label from your oil sample for the selected machine and component.




7

The sample is now linked to the machine and component. Use the "ADVANCED" data entry mode to add info.




8

Complete the sample info, take any pictures you want, add a comment if desired, then click the "submit sample" button




9

The sample info has been submitted to the laboratory where the QR code will be scanned, and the sample information automatically retrieved.



10

Submitted samples are listed. To update a samples info slide left. To delete a sample slide right.



11

Click "< Back" at the top of the previous screen to return to the component list so you can enter more samples for this machine.




MID:45403

Area
EDLCAR
Machine ID
Carbon Deutz 11-FILTER (S/N 220-2076)
Make/Model
Deutz TBG620



*Latest sample
tracking label*




MID:363491

Area
EDLCAR
Machine ID
Carbon Deutz 14-FILTER (S/N 220-3433)
Make/Model
Deutz TBG620



*Latest sample
tracking label*




MID:363483

Area
EDLCOV
Machine ID
CM 100 DRIVE
Make/Model
TUTHILL PD PLUS 7017



*Latest sample
tracking label*




MID:363516

Area
EDLCOV
Machine ID
CM 100 NON DRIVE
Make/Model
TUTHILL PD PLUS 7017



*Latest sample
tracking label*



MID:363484

Area
EDLCOV
Machine ID
CM 200 DRIVE
Make/Model
TUTHILL PD PLUS 7017



*Latest sample
tracking label*



MID:363507

Area
EDLCOV
Machine ID
CM 200 NON DRIVE
Make/Model
TUTHILL PD PLUS 7017



*Latest sample
tracking label*



MID:363513

Area
EDLCOV
Machine ID
CM 300 DRIVE
Make/Model
TUTHILL PD PLUS 7017



*Latest sample
tracking label*




MID:1429963

Area
EDLCOV
Machine ID
CM 300 NON DRIVE
Make/Model
TUTHILL PD PLUS 7017



*Latest sample
tracking label*




MID:126514

Area
EDLHAN
Machine ID
Royal Purple Synfilm gt 100 (S/N LR14-8885)
Make/Model
Roots 1016RGS



*Latest sample
tracking label*




MID:363474

Area
EDLLOR
Machine ID
EQ 103
Make/Model
TUTHILL BLOWER



*Latest sample
tracking label*




MID:363475

Area
EDLLOR
Machine ID
EQ 203
Make/Model
TUTHILL BLOWER



*Latest sample
tracking label*



MID:363482

Area
EDLLOR
Machine ID
EQ 303
Make/Model
TUTHILL BLOWER



*Latest sample
tracking label*