

Download the App



<https://bit.ly/oilapp>



<https://bit.ly/oaplay>

Download the Oil Analysis app from the App Store or Google Play. After installation, use your WebCheck credentials to login to the app.

Take your oil samples



1

Remove the sample label from the sample form and stick to the sample bottle.



2

Take the oil sample as you normally would and re-cap the sample bottle.



3

Ensure that the cap is securely tightened and wipe any excess oil from the sample bottle.

Complete sample submission with the asset tag booklet & the app



4

Using the app, scan the QR code of the machine the sample was taken from. Remove the tracking label from the sample form and stick to the asset log booklet.



5

Next, scan the sample label, and complete the sample information and submit the sample.



1

Login to the app using your WebCheck credentials. The app will cache your machines.




2

Once logged in, click on the "Scan QR Code" button.



3

Locate the machine that was sampled in the asset tag booklet and scan that QR code.




4

The asset is selected & sample submission screen is loaded. Click the "Scan" button.




5

Scan the sample bottle label from your oil sample for the selected machine.




6

The sample is now linked to the machine. Use the "SIMPLE" data entry mode to add info.



7

Select the sample date, take any pictures you want, add a comment if desired, then click the "submit sample" button




8

The sample info has been submitted to the laboratory where the QR code will be scanned, and the sample information automatically retrieved.



9

Submitted samples are listed. To update a samples info slide left. To delete a sample slide right.




EID:3389233

Area
{unassigned}
Machine ID
FOS3_U2120 FOS3_U2120_M2120
Component
Non-Drive End Bearing
Make/Model
SIEMENS



Latest sample tracking label




EID:3389234

Area
{unassigned}
Machine ID
FOS3_U2120 FOS3_U2120_M2120
Component
Drive End Bearing
Make/Model
SIEMENS



Latest sample tracking label




EID:3389245

Area
{unassigned}
Machine ID
FOS3_U2120 FOS3_U2120_P2120
Component
Non-Drive End Pump
Make/Model
SULZER



Latest sample tracking label




EID:3389247

Area
{unassigned}
Machine ID
FOS3_U2120 FOS3_U2120_P2120
Component
Drive End Pump
Make/Model
SULZER



Latest sample tracking label




EID:3389066

Area
{unassigned}
Machine ID
FOS3_U2120 FOS3_U2120_SS2120
Component
Drive End Seal Pot
Make/Model



Latest sample tracking label




EID:3389216

Area
 {unassigned}
 Machine ID
FOS3_U2120 FOS3_U2120_SS2120
 Component
 Non-Drive End Seal Pot
 Make/Model
 SULZER



Latest sample tracking label




EID:3389228

Area
 {unassigned}
 Machine ID
FOST_B3220 FOST_B3220_M3220
 Component
 Drive End Bearing
 Make/Model
 TECO



Latest sample tracking label




EID:3389219

Area
 {unassigned}
 Machine ID
FOST_U2220 FOST_U2220_M2220
 Component
 Lube System
 Make/Model



Latest sample tracking label




EID:3389222

Area
 {unassigned}
 Machine ID
FOST_U2220 FOST_U2220_M2220
 Component
 Non-Drive End Bearing
 Make/Model
 TECO



Latest sample tracking label




EID:3389223

Area
 {unassigned}
 Machine ID
FOST_U2220 FOST_U2220_M2220
 Component
 Drive End Bearing
 Make/Model
 TECO



Latest sample tracking label



EID:3389238

Area

{unassigned}

Machine ID

FOST_U2220 FOST_U2220_P2220

Component


Drive End Pump

Make/Model

SULZER



*Latest sample
tracking label*



EID:3389243

Area

{unassigned}

Machine ID

FOST_U2220 FOST_U2220_P2220

Component

Non-Drive End Pump

Make/Model

SULZER



*Latest sample
tracking label*