

### Download the App



<https://bit.ly/oilapp>



<https://bit.ly/oaplay>

Download the Oil Analysis app from the App Store or Google Play. After installation, use your WebCheck credentials to login to the app.

### Take your oil samples



1

Remove the sample label from the sample form and stick to the sample bottle.



2

Take the oil sample as you normally would and re-cap the sample bottle.



3

Ensure that the cap is securely tightened and wipe any excess oil from the sample bottle.

### Complete sample submission with the asset tag booklet & the app



4

Using the app, scan the QR code of the machine the sample was taken from. Remove the tracking label from the sample form and stick to the asset log booklet.



5

Next, scan the sample label, and complete the sample information and submit the sample.



1

Login to the app using your WebCheck credentials. The app will cache your machines.



2

Once logged in, click on the "Scan QR Code" button.



3

Locate the machine that was sampled in the asset tag booklet and scan that QR code.



4

The asset is selected & sample submission screen is loaded. Click the "Scan" button.



5

Scan the sample bottle label from your oil sample for the selected machine.



6

The sample is now linked to the machine. Use the "SIMPLE" data entry mode to add info.



7

Select the sample date, take any pictures you want, add a comment if desired, then click the "submit sample" button



8

The sample info has been submitted to the laboratory where the QR code will be scanned, and the sample information automatically retrieved.



9

Submitted samples are listed. To update a samples info slide left. To delete a sample slide right.



EID:1433121


Area  
**FORD FORD 450 SUPER DUTY**

Machine ID  
**FORD 450 SUPER DUTY**

Make/Model



*Latest sample  
tracking label*



EID:1957512

Area  
**FORD PLU 1**

Machine ID  
**FORD PLU 2003**

Make/Model



*Latest sample  
tracking label*



EID:1957566


Area  
**FORD PLU 1**

Machine ID  
**FORD PLU 2003**

Make/Model  
**1FTNW21FF3EA64139**



*Latest sample  
tracking label*



EID:1957567


Area  
**FORD PLU 1**

Machine ID  
**FORD PLU 2003**

Make/Model  
**1FTNW21FF3EA64139**



*Latest sample  
tracking label*



EID:1957511


Area  
**JOHN DEERE 204**

Machine ID  
**JOHN DEERE TRUCK LOADER**

Make/Model  
**LU655CX007757**



*Latest sample  
tracking label*



EID:1957514


Area  
**JOHN DEERE 301**

Machine ID  
**JOHN DEERE**

Make/Model



*Latest sample  
tracking label*



EID:1957515

Area  
**JOHN DEERE 304**

Machine ID  
**JOHN DEERE RUBBER TIRE LOADER**

Make/Model  
**DW544HX577583**



*Latest sample  
tracking label*



EID:1433110


Area  
**JOHN DEERE BACKHOE 310**

Machine ID  
**JOHN DEERE BACKHOE 310**

Make/Model



*Latest sample  
tracking label*



EID:1379242


Area  
**JOHN DEERE DW544HX577583**

Machine ID  
**JOHN DEERE 544H LOADER**

Make/Model  
**DW544HX577583**



*Latest sample  
tracking label*



EID:1379244


Area  
**JOHN DEERE LV4710H370334**

Machine ID  
**JOHN DEERE 4710**

Make/Model  
**LV4710H370334**



*Latest sample  
tracking label*



EID:1433109


Area  
**JOHN DEERE TO700HX921648**

Machine ID  
**JOHN DEERE 700H**

Make/Model  
TO700HX921648



*Latest sample  
tracking label*



EID:1379243


Area  
**MACK 1M2B206C1PM011544**

Machine ID  
**MACK DM690S**

Make/Model  
1M2B206C1PM011544



*Latest sample  
tracking label*



EID:1402552


Area  
**VOLVO EC290LCC03104**

Machine ID  
**VOLVO EC290**

Make/Model  
EC290LCC03104



*Latest sample  
tracking label*



EID:1957517

Area  
**WESTERN STAR 10**

Machine ID  
**WESTERN STAR 1996**

Make/Model



*Latest sample  
tracking label*